



BASE COVERAGE - S2RV

Coverage	Time	Period	Distance	Units
Basic Axle- Detroit	36	Months	UNLIMITED	Miles
Basic Chassis	36	Months	50,000	Miles
Batteries	12	Months	100,000	Miles
Brightwork	6	Months	UNLIMITED	Miles
Cab Corrosion/Perforation	60	Months	UNLIMITED	Miles
Cab Structure	60	Months	UNLIMITED	Miles
Chassis Paint	6	Months	UNLIMITED	Miles
Corrosion	6	Months	UNLIMITED	Miles
Frame Rails and Crossmembers	60	Months	100,000	Miles
Ghg21 Tire (Direct File)	24	Months	24,000	Miles
Ghg21 Without A/C	60	Months	100,000	Miles
Paint	12	Months	100,000	Miles
Seals and Gaskets	36	Months	UNLIMITED	Miles
Tie Rod Assembly	12	Months	UNLIMITED	Miles
Tie Rod Boots	12	Months	UNLIMITED	Miles
Towing/Roadside Assistance	36	Months	50,000	Miles
Transfer Case	36		50,000	
Transmission (Direct File)	60	Months	200,000	Miles
B6.7 Cummins	60	Months	100,000	Miles

1 Because Warranty coverage is determined by a unit's specifications, gross combination weight rating, road surface, and vocation, coverage may vary. For unit-specific coverage, Dealers should enter a product serial number or vehicle identification number on the Coverage Info screen in OWL; for customers without access to OWL, see ordering Dealer for more information.

2 Time or distance, whichever comes first.

3 Applies to products spec'd with CARB engine and domicile certification codes. See separate owner's manual for engine coverage.

4 Applies to models 2023 and later domiciled in the United States. See separate owner's manual for engine coverage.

5 Customers will have only one (1) type of front/steer axle coverage, either Detroit or non-Detroit, depending on how the unit is spec'd.

6 Access Detroit parchments at DTNAConnect > Warranty Lit > Coverages > Detroit; for customers without access, see ordering Dealer for more information.

7 Customers will have only one (1) type of rear axle coverage, either Detroit or non-Detroit, depending on how the unit is spec'd.

8 Towing/Roadside Assistance fully reimbursed to the nearest Company authorized repairing location; for a DTNA warrantable repair in a vehicle-down situation, call 1-800-385-HELP

